

# ROTHENBERGER

## ROMAX 3000 AC

ROMAX 3000 AC



DE Bedienungsanleitung  
EN Instructions for use  
FR Instruction d'utilisation  
ES Instrucciones de uso  
IT Istruzioni d'uso  
NL Gebruiksaanwijzing  
PT Instruções de serviço  
DA Brugsanvisning  
SV Bruksanvisning  
NO Bruksanvisning  
FI Käyttöohje  
PL Instrukcja obsługi


CS Návod k používání  
TR Kullanım kilavuzu  
HU Kezelési útmutató  
BG Инструкции за експлоатация  
ET Kasutusjuhend läbi  
LT Naudojimo instrukcija  
LV Lietošanas pamācība  
EL Οδηγίες χρήσεως  
RU Инструкция по использованию  
AR دليل الاستخدام  
ZH 使用说明书



rothenberger.com

# Overview

no. 1000001089 ROMAX 3000 AC basic 230V




## A Emergency-Off / ON-Switch / Positions


1 EMERGENCY-OFF



2 ON-SWITCH



3 VARIOUS POSITION





Insert Press Jaw C

