

# ROTHENBERGER

## ROMAX 4000

ROMAX 4000  
Charger / Battery




DE Bedienungsanleitung  
EN Instructions for use  
FR Instruction d'utilisation  
ES Instrucciones de uso  
IT Istruzioni d'uso  
NL Gebruiksaanwijzing  
PT Instruções de serviço  
DA Brugsanvisning  
SV Bruksanvisning  
NO Bruksanvisning  
FI Käyttöohje  
PL Instrukcja obsługi  
CS Návod k používání  
TR Kullanım kilavuzu

HU Kezelési útmutató  
SL Navodilo za uporabo  
SK Návod na obsluhu  
HR Upute za uporabu  
BG Инструкция за експлоатация  
RO Manualul de utilizare  
ET Kasutusjuhend läbi  
LT Naudojimo instrukcija  
LV Lietošanas pamācība  
EL Οδηγίες χρήσεως  
RU Инструкция по использованию  
AR دليل الاستخدام  
JA マニュアル



[rothenberger.com](http://rothenberger.com)

No.: 1200001764 ROMAX 4000 basic



## A Changing Battery



## B Emergency-Off / ON-Switch / Positions





# Insert Press Jaw D

<p>1</p> <p>Diagram 1 shows the red press jaw being inserted into the handle. Red arrows indicate the direction of insertion.</p>	<p>Diagram 1 continued shows the red press jaw fully inserted into the handle. Red arrows indicate the direction of insertion.</p>
<p>2</p> <p>Diagram 2 shows the red press jaw being pushed into the handle. Red arrows indicate the direction of pushing.</p>	<p>Diagram 2 continued shows the red press jaw fully pushed into the handle. Red arrows indicate the direction of pushing.</p>
<p>3</p> <p>Diagram 3 shows the red press jaw being rotated into the handle. Red arrows indicate the direction of rotation.</p>	<p>Diagram 3 continued shows the red press jaw fully rotated into the handle. Red arrows indicate the direction of rotation.</p>